

ALIFE VINYL FLOORS REQUIRE LITTLE MAINTENANCE TO LOOK AMAZING YEAR AFTER YEAR. CLEANING AND MAINTENANCE FREQUENCY VARIES BASED ON SPECIFIC TRAFFIC VOLUME AND AREA OF USE. WALK-OFF MATS, DAILY SWEEPING AND A REGULAR CLEANING SCHEDULE WILL REDUCE DAILY DIRT, DUST AND BUILD-UP AND MINIMIZE THE NEED FOR MORE EXTENSIVE MAINTENANCE STEPS.

IMMEDIATE CARE AFTER INITIAL INSTALLATION: LVT Loose Lay, LVT Click & SPC

- + A MINIMUM 1/4" PLYWOOD SHOULD BE USED TO COVER A NEW FLOOR WHEN MOVING HEAVY OBJECTS.
- + SWEEP, DUST MOP OR VACUUM (WITHOUT A BEATER BAR) THOROUGHLY.
- + KEEP THE ROOM TEMPERATURE BETWEEN 65° F AND 85° F.
- + ONCE THE FLOOR HAS BEEN PROPERLY INSTALLED, YOU CAN BEGIN TO PERFORM REGULAR MAINTENANCE.

IMMEDIATE CARE AFTER INITIAL INSTALLATION: LVT DRY BACK

- + ADHESIVE RESIDUE MAY BE REMOVED WITH A CLEAN WHITE CLOTH LIGHTLY DAMPENED WITH MINERAL SPIRITS.
- + A MINIMUM 1/4" PLYWOOD SHOULD BE USED TO COVER A NEW FLOOR WHEN MOVING HEAVY OBJECTS.
- + DO NOT WET WASH OR SCRUB FLOORS FOR AT LEAST 7 DAYS AFTER INSTALLATION TO ALLOW THE NEW FLOOR TO PROPERLY BOND TO THE SUBSTRATE AND PREVENT ANY MOISTURE INTERFERENCE WITH THE ADHESIVE. LIGHTLY DAMP MOP IF NEEDED.
- + SWEEP, DUST MOP, OR VACUUM (WITHOUT A BEATER BAR) THOROUGHLY.
- + KEEP THE ROOM TEMPERATURE BETWEEN 65° F AND 85° F.
- + ONCE THE FLOOR HAS PROPERLY SET, YOU CAN BEGIN TO PERFORM REGULAR MAINTENANCE.

REGULAR MAINTENANCE

- + THESE FLOORS CAN BE EASILY MAINTAINED WITH DAMP MOPPING USING A NEUTRAL VINYL FLOOR CLEANER WHEN NEEDED. THESE PRODUCTS DO NOT REQUIRE WAXING OR POLISHING, BUT MAY BE WAXED OR POLISHED, IF DESIRED.
- + SWEEP, DUST MOP, OR VACUUM THOROUGHLY TO REMOVE ALL DIRT AND GRIT.
- + DAMP MOP WITH A NEUTRAL VINYL FLOOR CLEANER FOLLOWING THE CLEANER PRODUCT INSTRUCTIONS FOR PROPER USAGE AND DILUTION RATE IF REQUIRED.
- + RINSE (DO NOT FLOOD) WITH CLEAN WATER.
- + ALWAYS REMOVE EXCESS WATER AND ALLOW FLOOR TO FULLY DRY.
- + WHEN UTILIZING A LOW RPM MACHINE OR AUTO SCRUBBER, USE

ADDITIONAL RECOMMENDATIONS

- + AVOID CLEANERS THAT CONTAIN ABRASIVES OR SOLVENTS, WHICH CAN PERMANENTLY DAMAGE THE FLOOR.
- + IF USING WALK-OFF MATS, PLACE WALK-OFF MATS AT ALL ENTRANCES AS WIDE AS THE DOOR AND LONG ENOUGH TO ACCOMMODATE THE SOIL LOAD AND WEATHER CONDITIONS. BE SURE TO USE ONLY NON-STAINING MATS THAT DO NOT FEATURE A LATEX OR RUBBER BACKING AS THESE BACKINGS MAY CAUSE PERMANENT DISCOLORATION TO THE VINYL FLOOR.
- + VACUUM ANY MATS OR AREA RUGS REGULARLY.
- + USE FLOOR PROTECTORS, MEASURING AT LEAST 1" IN DIAMETER, UNDER FURNITURE TO REDUCE INDENTATION. GENERALLY, THE HEAVIER THE ITEM, THE WIDER THE FLOOR PROTECTOR NEEDS TO BE.
- + USE OF BLINDS OR CURTAINS IS RECOMMENDED FOR PEAK SUNLIGHT HOURS TO PREVENT DISCOLORATION OR DAMAGE DUE TO EXCESSIVE TEMPERATURE VARIATIONS.
- + ALWAYS USE WET FLOOR SIGNS IN COMMERCIAL APPLICATIONS WHEN PERFORMING ANY WET MAINTENANCE.

FOR QUESTIONS REGARDING THE MAINTENANCE OF YOUR ALIFE VINYL FLOOR, PLEASE CONTACT US AT INFO@ALIFEFLOOR.COM